

Dornbracht

Sensory Sky

Manual

2	Safety information	35	Replacement of fragrance bottles
3	Logic controls	37	Reordering fragrance bottles
21	Display button	21	Display button
23	Rotary knob	23	Rotary knob
5	Functions	24	Temperature adjustment
28	Waiting display	25	Individual configuration
31	On/Off	26	Resetting all outlet points
27	Volume adjustment	27	Volume adjustment
24	Temperature adjustment	28	Waiting display
25	Individual configuration	31	On/Off
26	Resetting all outlet points	34	Starting a choreography
16	Choreographies	35	Replacement of fragrance bottles
34	Starting a choreography	37	Reordering fragrance bottles
18	Fragrance	40	General terms and conditions
40	General terms and conditions	42	Service Display

44 Disposal

42 General information

44 Cleaning

42 Service Display

44 Maintenance

45 Safety deactivation

44 Disposal

44 Maintenance

44 Cleaning

45 Safety deactivation

Please read this operating manual in full before using the SENSORY SKY for the first time.
Other language versions are available on the Internet at:



Safety information

The SENSORY SKY can be used by children of 8 years old and over, and also by persons with restricted physical, sensory or mental capacity or lack of experience and knowledge, if they are supervised or have been instructed on safe use of the appliance and understand the resulting risks. Children must not be allowed to play with the appliance. Cleaning and maintenance must not be carried out by children without supervision.


Because small quantities of a fragrance are added to the water emerging from SENSORY SKY, we are legally obliged to inform you that the water that emerges from SENSORY SKY is not drinking water.

Logic controls

Display button


- 1 = Head spray On/Off
- 2 = Rain curtain On/Off
- 3 = Hand shower On/Off
- 4 = Body spray On/Off

Display button 1




- 5 = reAdjust On/Off
- 6 = reJoyce On/Off
- 7 = Cold-water mist On/Off
- 8 = reLease On/Off

Display button 2




- 9 = Fragrance reAdjust On / Off
- 10 = Fragrance reJoyce On/Off
- 11 = Shower zone lighting On / Off
- 12 = Fragrance reLease On/Off

Display button 3




Rotary knob

Volume



Temperature



Functions

Sleep mode




The Sensory SkyATT has an automatic sleep mode. The system can be woken up and made ready for use by pressing or turning any control element. If it is not used for 60 minutes, the System will return to automatic sleep mode. The pre-defined water volume is 80%, the pre-defined temperature 38°C. Individual settings are saved for five minutes after the water has been switched off.

Ready - Display button 1



Ready - Display button 2



Ready - Display button 3




Waiting display

If a function has been selected but is not yet ready (e.g. the set temperature), the appropriate symbol will flash. It will stop flashing as soon as the function is ready for use.




On/Off


using rotary knob




using rotary knob



using display button




Cold-water mist




The temperature and volume cannot be adjusted.

Light




The light colour and intensity cannot be adjusted.

Fragrance




The fragrance is automatically supplied in the water in the rain curtain. It is not possible to activate more than one fragrance at any one time

Volume adjustment



Temperature adjustment



Disable scalding protection system




1 = turn to max

2= push + turn at the same time





The scald protection system will be re-enabled after 10 minutes.

Individual configuration



If several outlet points are active at the same time, individual points can be selected by pressing and holding them. The temperature and volume can then be set individually for this outlet point.



Resetting all outlet points

Pressing both rotary knobs at the same time will reset the temperature and volume to their default values.



Type: Sensory Sky
Power consumption: max. 180 W
Nominal voltage: 100 - 240V ~ 50 - 60 Hz
Nominal current: 4,5 A
Protection (control elements): IP X4
Protection control and distribution unit (motherboard,
eValve, lighting control module): IP 54



Aloys F. Dornbracht GmbH & Co. KG Armaturenfabrik
Köbbingser Mühle 6, D-58640 Iserlohn
Tel. +49(0)2371 433-0, Fax +49(0)2371 433-232
mail@dornbracht.de, dornbracht.com

Dornbracht Group

Premium Solutions for Interior Architecture

Choreographies

You can choose between two automatic scenarios:

1 reAdjust

READJUST sharpens the senses. Mist and warm rain reduce the daily flood of stimuli to a pleasant minimum – until the sky gradually clears and perception is more focussed and intensified: where is this pleasantly soft dry forest floor fragrance coming from?


2 reRelease

RELEASE is an intensive summer rain which is both cleansing and liberating. Accumulated energies erupt in an expressive choreography composed of different types of rain and different temperatures – accompanied by a refreshing, tropical-like fragrance.

3 reJoice

REJOICE protects, envelops and stabilises. The external rain curtain is a projection screen for the light with water drops sparkling in all the colours of the rainbow – a multifaceted, harmonious interplay of colours and fragrances which is gradually transferred to the whole body.

Starting a choreography

 During a choreography temperature may be changed by +/- 2°C and water volume by +/- 20%. Pressing any rotary knob or display button enables you to terminate a choreography prematurely.



Fragrance

The fragrances to match the choreographies are a special feature of SENSORY SKY. Just like the water and light settings they are inspired by weather phenomena and the moods of Mother Nature. The fragrances enhance the choreography and help your feeling of well-being – both consciously and unconsciously. They can also be selected independently of the choreographies to enrich your individual shower experience. All fragrances are made of high-quality, natural and nature-identical essential oils, aromas and balsams and have been approved by the International Fragrance Association (IFRA).

The fragrance for reAdjust

Warm, green, balsamic fragrance with a fresh woody tone and a herbaceous, sweet fruity character. Relaxes, liberates and strengthens, acts mainly via the psyche, lifts your mood. A mixture of needle notes, orange citrus fragrances, meadow herbs and berries.

The fragrance for reLease

Fresh green grassy citrus fragrance to the fore with an earthy, moss base. Refreshes, has an earthing effect, strengthens and balances and also lifts your mood via your psyche. A mixture of chlorophyll, birch, lemon grass and citrus notes.

The fragrance for reJoyce

A poetic “wave-shaped” composition which has an illuminating, stimulating and flowery effect. Green, fresh and clear to the fore with a sweet, spicy and woody, warm character. A mixture of green leaves, mint, warm wood notes and herb fragrances.


General terms and conditions

We accept liability for our products on the basis of the statutory regulations as long they have been installed, maintained and operated in accordance with our specifications. We do not have any experience about the suitability of other fragrances and therefore we cannot accept any liability if you use substances other than those we recommend.

Replacement of fragrance bottles




As soon as a fragrance is empty, the icon will be shown in grey. This is a request to replace the fragrance bottle. The 200 ml bottle will last for approx. 230 minutes at default settings.



Proceed as shown in drawings 1 to 4 to replace a fragrance bottle.

Confirm replacement



Please follow the safety instructions on the label and on the instruction leaflet of the fragrance when replacing and disposing of the completely empty bottles.

Reordering fragrance bottles

All the information you need to (re)order SENSORY SKY fragrances is available at:




<http://dornbracht.com/sensory-sky>

Display button


- 1 = Head spray On/Off
- 2 = Rain curtain On/Off
- 3 = Hand shower On/Off
- 4 = Body spray On/Off

Display button 1




- 5 = reAdjust On/Off
- 6 = reJoyce On/Off
- 7 = Cold-water mist On/Off
- 8 = reLease On/Off

Display button 2




- 9 = Fragrance reAdjust On / Off
- 10 = Fragrance reJoyce On/Off
- 11 = Shower zone lighting On / Off
- 12 = Fragrance reLease On/Off

Display button 3




Rotary knob

Volume



Temperature



Temperature adjustment



Disable scalding protection system




1 = turn to max

2= push + turn at the same time





The scald protection system will be re-enabled after 10 minutes.

Individual configuration



If several outlet points are active at the same time, individual points can be selected by pressing and holding them. The temperature and volume can then be set individually for this outlet point.




Resetting all outlet points

Pressing both rotary knobs at the same time will reset the temperature and volume to their default values.



Volume adjustment



Waiting display

If a function has been selected but is not yet ready (e.g. the set temperature), the appropriate symbol will flash. It will stop flashing as soon as the function is ready for use.




Sleep mode




The Sensory SkyATT has an automatic sleep mode. The system can be woken up and made ready for use by pressing or turning any control element. If it is not used for 60 minutes, the System will return to automatic sleep mode. The pre-defined water volume is 80%, the pre-defined temperature 38°C. Individual settings are saved for five minutes after the water has been switched off.

Ready - Display button 1



Ready - Display button 2




Ready - Display button 3



On/Off


using rotary knob




using rotary knob



using display button




Cold-water mist




The temperature and volume cannot be adjusted.

Light




The light colour and intensity cannot be adjusted.

Fragrance



The fragrance is automatically supplied in the water in the rain curtain. It is not possible to activate more than one fragrance at any one time

Starting a choreography


 During a choreography temperature may be changed by +/- 2°C and water volume by +/- 20%. Pressing any rotary knob or display button enables you to terminate a choreography prematurely.



Replacement of fragrance bottles




As soon as a fragrance is empty, the icon will be shown in grey. This is a request to replace the fragrance bottle. The 200 ml bottle will last for approx. 230 minutes at default settings.



Proceed as shown in drawings 1 to 4 to replace a fragrance bottle.

Confirm replacement



 Please follow the safety instructions on the label and on the instruction leaflet of the fragrance when replacing and disposing of the completely empty bottles.

You can choose between two automatic scenarios:

1 reAdjust

READJUST sharpens the senses. Mist and warm rain reduce the daily flood of stimuli to a pleasant minimum – until the sky gradually clears and perception is more focussed and intensified: where is this pleasantly soft dry forest floor fragrance coming from?

2 reRelease

RELEASE is an intensive summer rain which is both cleansing and liberating. Accumulated energies erupt in an expressive choreography composed of different types of rain and different temperatures – accompanied by a refreshing, tropical-like fragrance.

3 reJoice

REJOICE protects, envelops and stabilises. The external rain curtain is a projection screen for the light with water drops sparkling in all the colours of the rainbow – a multifaceted, harmonious interplay of colours and fragrances which is gradually transferred to the whole body.

Reordering fragrance bottles

All the information you need to (re)order SENSORY SKY fragrances is available at:



<http://dornbracht.com/sensory-sky>

The fragrances to match the choreographies are a special feature of SENSORY SKY. Just like the water and light settings they are inspired by weather phenomena and the moods of Mother Nature. The fragrances enhance the choreography and help your feeling of well-being – both consciously and unconsciously. They can also be selected independently of the choreographies to enrich your individual shower experience. All fragrances are made of high-quality, natural and nature-identical essential oils, aromas and balsams and have been approved by the International Fragrance Association (IFRA).

The fragrance for reAdjust

Warm, green, balsamic fragrance with a fresh woody tone and a herbaceous, sweet fruity character. Relaxes, liberates and strengthens, acts mainly via the psyche, lifts your mood. A mixture of needle notes, orange citrus fragrances, meadow herbs and berries.

The fragrance for reLease

Fresh green grassy citrus fragrance to the fore with an earthy, moss base. Refreshes, has an earthing effect, strengthens and balances and also lifts your mood via your psyche. A mixture of chlorophyll, birch, lemon grass and citrus notes.

The fragrance for reJoyce

A poetic “wave-shaped” composition which has an illuminating, stimulating and flowery effect. Green, fresh and clear to the fore with a sweet, spicy and woody, warm character. A mixture of green leaves, mint, warm wood notes and herb fragrances.

General terms and conditions

We accept liability for our products on the basis of the statutory regulations as long they have been installed, maintained and operated in accordance with our specifications. We do not have any experience about the suitability of other fragrances and therefore we cannot accept any liability if you use substances other than those we recommend.

Service Display

If one of the symbols is lit in red for 2 seconds, contact your dealer or the Dornbracht Service Department.



Disposal


All electronic elements are marked in compliance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). This Directive provides the framework for the return and recycling of end of life products throughout the EU. In addition to valuable recyclable materials, end of life electrical and electronic appliances also contain harmful substances. These can be harmful to human health and the environment if they are disposed of in the residual non-recyclable waste or if they are not treated correctly. You should therefore never dispose of your waste appliance as non-recyclable waste. Instead, use the collection point established by your local authority to return and recycle electrical and electronic waste. Ensure that you comply with the current regulations in this respect. You must also comply with other national regulations which apply.



General information

Cleaning

Key lock



5 sec.



Service Display

If one of the symbols is lit in red for 2 seconds, contact your dealer or the Dornbracht Service Department.



Maintenance

We recommend that you have all the components inspected and serviced by your plumber once per year. This maintenance will also include cleaning, checking for leaks, checking the functions and uploading the latest software version. A maintenance contract with an authorised plumber will ensure that your system is inspected regularly.

Safety deactivation

A safety deactivation system ensures that all active functions are switched off automatically after 30 minutes at the most.

Disposal

All electronic elements are marked in compliance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). This Directive provides the framework for the return and recycling of end of life products throughout the EU. In addition to valuable recyclable materials, end of life electrical and electronic appliances also contain harmful substances. These can be harmful to human health and the environment if they are disposed of in the residual non-recyclable waste or if they are not treated correctly. You should therefore never dispose of your waste appliance as non-recyclable waste. Instead, use the collection point established by your local authority to return and recycle electrical and electronic waste. Ensure that you comply with the current regulations in this respect. You must also comply with other national regulations which apply.




Maintenance

We recommend that you have all the components inspected and serviced by your plumber once per year. This maintenance will also include cleaning, checking for leaks, checking the functions and uploading the latest software version. A maintenance contract with an authorised plumber will ensure that your system is inspected regularly.

Cleaning

Key lock



Safety deactivation

A safety deactivation system ensures that all active functions are switched off automatically after 30 minutes at the most.

If you have any questions, contact the Dornbracht branch nearest you:

Dornbracht UK Ltd.
Units 8 & 9 Bow Court Fletchworth Gate Coventry CV5 6SP
Tel. +44(0)2476 717 129, Fax +44(0)2476 718 907
mail@dornbrachgroup.co.uk, www.dornbracht.com